

Radiola	Philips	Année
315A	930A	1932
535A	730A	1932
423A	830N	1933
445A et C	634A et C	1933
428A	834S	1934
561A et U	521A et U	1934
761(M)	572	1934
563A et U	510A et U	1935
567A et U	535A et U	1935
21A et U	582A et U	1936
67A et U	796A et U	1936
23A et U	V6A et U	1937
68A et U	750A et U	1937
10A et U	215A et U	1938
18A et U	555A et U	1938
85A	A2N	1939
90A et U	480A et U	1939
103A	855A	1939
185A	A102	1939
133U	A43U	1940
133UB	A43UB	1941
190A	A60A	1941
142A et U	52A et U	1942

Radiola	Philips	Année
425A	830A	1932
545A	630A	1932
427A	834AS	1933
547A(M)	630N	1933
549A et U	638A et U	1934
562A et U	522A et U	1934
762(M)	572 Luxe	1934
564A et U	525A et U	1935
42A et U	456A et U	1936
78A	898A	1936
43A et U	461A et U	1937
247/248(AR)	247/248	1937
12A et U	470A et U	1938
21B	628B	1938
86A	A446	1939
94A et U	680A et U	1939
112B	629B	1939
228B	228B	1939
134U	A44U	1940
138U	A48U	1941
161A	761A	1946

Radiola	Philips	Année
426A	830A+TD	1932
546A	630A	1932
427C	834CS	1933
548A(M)	630N	1933
560A et U	520A et U	1934
566A et U	526A et U	1934
565A	535A Luxe	1935
56A et U	695A et U	1936
Pionnier A et U	V4A et U	1936
57A et U	667A et U	1937
249/250B (AR)	249/250B	1937
17A	753A	1938
24A et U	660A et U	1938
87U	A4U	1939
97A et U	735A et U	1939
132U	A42U	1939
268/69B	268/69B	1939
186A	A446	1940
139A	A49A	1941

539A	A449A	1946
191A	A61	1946
RA82U	BF281U	1948
RA93A	BF393A	1949
RA81U02	BF183U	1949
RA11U	BF101U	1950
RA282U	BF290U	1950
RA50A	BF501A	1950
RA35A et U	BF311A et U	1951
RA15U	BF111U	1951
RA152U	BF121U	1952
RA452A	BF421A	1952
RA152A	BF121A	1953
RA125A/02 et U	BF102A/02 et U	1954
RA391A	HF448A	1954
RA155A et U	BF151A et U	1955
RA347A	HF453A	1955
RA157U	B1F17U	1956
RA127A et U	B1F03A et U	1957
RA157A	B1F17A	1958
RA316T	L3F60T	1958
RA128A	B1F12A	1959
RA389T	L3F83T	1959

590A	A460A	1946
RA84A	BF480A	1949
RA940A	BF491A	1949
RA81U/02	BF181U	1950
RA40A	BF401A	1950
RA47A	BF412A	1951
RA35A et U	BF331A et U	1951
RA262U	BF223U	1952
RA126A FM	BF621A	1952
RA264U	BF241U	1954
RA265U	BF251U	1955
RA177A	B1F71A	1957
RA268U	B2F70U	1958
RA468A	B4F70A	1958
RA209A	B2F90A	1959

538U	A448U	1946
RA81U01	BF183U	1949
RA81U/01	BF183U	1950
RA46A	BF406A	1950
RA305UB	LF503UB	1951
RA352A	BF321A	1952
RA363A	BF331A	1954
RA364A	BF341A	1954
RA455A	BF451A	1955
RA428A	B4F75A	1957
RA278A	B2F80A	1958
RA369A	B3F85A	1959

RA119A	B1F07A	1960
RA130U	B1F20U	1961
RA3231A	22RB371/00	1966
RA4246 AM/FM	B5W32AT/02	