





207 CC



Réf: 9690.09




1.80 H





6




10  
16



20



PPS









P.7





P.8



P.9



P.10




P.9



P.12



P.12




P.11/18

①



a




②



a



b



2 x ✂

c



1 x ✂


3



4



5



6




7




1 X

1 X

8




9



20 3 x

10



11



1 x




4 x





12




13




14



15




16








17



18






19





20



# BSI




21




22




23




24




b 2 x 





F	Option	SP	Opción
GB	Option	P	Opção
NL	Optie	I	Opzjon
D	Sonderausstattung	PL	Opcja
H	Opció	DK	Option
CZ	Doplnek		

Réf	Push		USB
8218 Y0	3	1	-
8218 VV	3	1	1
8218 VW	6	-	1

25




26




27



28



29



30



31




32




33



34



2 x \*



1 x \*

35





36





a

b



37



38



PPS



39











**Réf: 9471.AH**

F	Option	SP	Opción
GB	Option	P	Opção
NL	Optie	I	Opzion
D	Sonderausstattung	PL	Opcja
H	Opció	DK	Option
CZ	Doplnek		



a 2 x 





# PPS



**hyper-fréquence**  
=  
**anti-soulèvement**



Alarme  
Alarm  
Alarmanlage  
Alarmsysteem  
La alarma  
O Alarme  
Allarme  
Alarm  
Alarm  
Riasztóberendezés  
Alarm  
Alarm



Guide d'utilisation



**207 CC**

